


DIAGRAM OF C21/51-A1



ITEM NO.	PART NO.	DESCRIPTION	ITEM NO.	PART NO.	DESCRIPTION	ITEM NO.	PART NO.	DESCRIPTION
101	2040101-03050-2	HEX.SOC.HD.BOLT	209	2041102-01030-0	O - RING	428	2040101-03100-0	HEX.SOC.HD.BOLT
102	11381-0464701-1	WASHER	210	11373-0084701-1	TRIGGER VALVE HEAD	429	2040101-04090-2	HEX.SOC.HD.BOLT
103	11371-0784701-2	DEFLECTOR	211	2040400-05060-0	SPRING PIN	430	1134C-1004701-1	SAFETY COVER
104	1132T-0780001-1	MUFFLER	212	2040400-05110-0	SPRING PIN	431	2040501-03040-0	BOLT CAP
105	1135G-0460001-1	RUBBER PAD	213	2040400-05160-0	SPRING PIN	432	11338-1074701-1	SAFETY GUIDE
106	11369-1004301-2	CAP	215	11224-0254701-1	TRIGGER UNIT	434	11337-0084701-1	SAFETY SPRING
107	2040101-03110-0	HEX.SOC.HD.BOLT	301	11230-0764202-1	GUN BODY UNIT	435	11330-1074703-1	SAFETY
108	11381-0760001-1	WASHER	302	11346-0081301-1	END CAP	443	11355-1004701-1	MAGAZINE COVER
109	11360-0760002-1	COMPRESSION SPRING	303	2041109-05050-0	O - RING	444	1134N-0250002-1	SPRING BASE A
110	11368-0760002-1	HD.VALVE PISTON	306	1135R-0764701-1	PROTECTIVE CUSHION	445	11328-0764701-1	PULL SPRING
111	2041104-05050-0	O - RING	401	11382-1074701-2	NOSE PIECE	446	11356-0784702-1	SPACER
112	2041101-06020-0	O - RING	402	2041104-05020-0	O - RING	447	11354-1004701-1	MAGAZINE CASE
113	1133M-0760001-1	SEAL GASKET	403	11364-0764702-1	FEED PISTON	448	1134M-0250002-1	SPRING BASE
114	11370-0760002-1	SEAL	404	2041109-01050-0	O - RING	449	1135H-0250001-1	SHAFT RING
115	11399-0760003-1	COLLAR	405	2041100-02040-0	O - RING	450	2040101-03161-0	HEX.SOC.HD.BOLT
116	1132M-0764701-1	PACKING	406	2041109-01060-0	O - RING	451	2040202-03010-0	FLAT WASHER
117	2041104-04102-0	O - RING	407	1133J-0524701-1	SPRING A COMPRESSION	453	2040500-03020-0	LOCK NUT
118	11204-1000001-2	DRIVER UNIT	408	1134W-0810001-1	FEED BUMPER	454	11383-1000001-1	MUZZLE PROTECTOR
119	11320-1000001-2	CYLINDER	409	11366-0814701-1	FEED PISTON CAP	455	11324-0254701-1	FIXED PIN
120	2041108-05040-0	O - RING	410	2040300-01010-0	C - RING	456	1131G-0254701-1	FIXED RING
121	11321-0070002-1	CYLINDER SPACER	411	11306-1004701-1	FEED FINGER	460	2041109-01030-0	O - RING
122	2041108-07020-0	O - RING	412	11307-0780001-1	FEED FINGER SPRING			
123	11322-0250001-1	CYLINDER RING	414	1135H-0790001-1	PU RETAINER			
124	11327-0764702-1	BUMPER	415	1130G-0764701-1	FIRST STOPPER FINGER			
125	1131E-0764701-2	CYLINDER PRESS RING	416	1131D-0460001-1	URETHANE RETAINER			
201	2041104-02020-0	O - RING	417	1130H-1000001-1	SPRING			
202	2041104-02030-0	O - RING	418	11365-0664701-1	PIN FEED PISTON			
203	11374-0084701-1	PLUNGER CAP	419	11359-1004701-1	PIN-NAIL STOP			
204	1133S-0250001-1	VALVE PLUNGER	420	11362-0784702-1	DOOR SHAFT PIN			
205	2041100-01070-0	O - RING	421	11361-1074701-1	DOOR			
206	2041100-01030-0	O - RING	422	11311-0794701-1	LATCH SPRING			
207	11376-0254701-1	SPRING	423	11310-0794701-1	DOOR LATCH			
208	11375-0084701-1	PLUNGER	424	2040400-05050-0	SPRING PIN			